Press



NOTE: Tape edges of battery down. Leave middle exposed for copper contact